

The <sup>upper</sup> middle line of the <sup>whitely</sup> fender will meet the line of the bank at 32 feet from the head of the lock, measuring along the <sup>top</sup> surface of the fender.

The studs of the upper side of the breast and wing walls will be tenoned into the bottom sill. The studs of the lower side of the breast will run down to the bottom plank & will have the second course fitted around them. The studs both above & below the breast will be tenoned into the sills lying on the top of the breast. The sills on the breast will run into the wall as far as the back of the studs -

below top of coping

